


# 32 Channel PET/MR 3.0T Installation Interconnect Map with eSRPS – Magnet Room (MP26)



**Symbol Legend**

Ball Valve
 Check Valve

**Interconnects Numbering Legend**

**First Character (one-digit alpha):**

- Exxxx Runs in Equipment Room or Control Room
- Mxxxx Runs entirely in the Magnet Room
- Pxxxx Runs through PEN or SPW and routed in Magnet and Equipment Room

**Subsequent Characters:**

- 0xxxx AC Power & Ground
- 1xxxx Coax/RF
- 2xxxx Fiber Optics
- 3xxxx Signal
- 4xxxx Other

-- Dotted lines for module outlines or cables indicate an option